



Spare parts suitable for: **FORVED**

Spare parts suitable for small appliances and single devices




Toasters/salamanders




Item	Order	Description	Model	OEM
1	416871	800W/230V	FT2	TOSTRES01
2	416872	1000W/230V	FT3/FT6	TOSTRES02
3	416873	500W/230V	FT4/FT8, S60	TOSTRES04



Item	Order	Description	Model	OEM
1	416874	450W, 110V	FT3/FT6	TOSTRESCOR
2	416875	660W, 110V	FT4/FT8	TOSTRESCOR1
3	416876	760mm	SA80	SALAMADRES



Item	Order	Description	Model	OEM
1	350032	timer	FT2	TOSTtimer
2	110366	knob	FT3	TOSTtimerMAN
3	301003	switch	FT4	TOSTINTER
4	359143	signal lamp	FT8	TOSTLAMP



Item	Order	Description	Model	OEM
1	375002	thermostat		GRILLTERMOS
2	111584	knob	SA60	GRILLTERMOSMA
3	301003	switch	SA80	TOSTINTER
4	359143	signal lamp		GRILLGEMMA



Item	Order	Description	Model	OEM
1	380238	contactor	SA80	SALAMANDCONT
2	690010	pliers	FT__	TOSTPINZA

Pizza ovens




Item	Order	Description	Model	OEM
1	416874	450W/110V	FP,	TOSTRESCOR
2	850064	firebrick	FP2	FORNOPIASTRE




Item	Order	Description	Model	OEM
1	375002	thermostat		GRILLTERMOS
2	111584	knob	FP,	GRILLTERMOSMA
3	359143	signal lamp	FP2	GRILLLAMPAD

Contact grills




Item	Order	Description	Model	OEM
1	416877	1000W/230V (upper)	FBSL, FBSR,	GRILLRES02
2	416878	1400W/230V (lower)	FBD, FBDL,	GRILLRES01
3	416879	1200W/230V (upper)	FBMR	GRILLRES03
4	416880	1700W/230V (lower)		GRILLRES04




Item	Order	Description	Model	OEM
1	375002	thermostat	FBSL	GRILLTERMOS
2	300176	switch	FBSR	03227/A
3	111584	knob	FBMR	GRILLTERMOSMA
4	359143	signal lamp	FBD	
5	359142	signal lamp	FBDL	GRILLLAMPAD

Vitrines




Item	Order	Description	Model	OEM
1	693199	spring	FBS	GRILLMOLLA
2	693200	handle	FBD FBMR	GRILLIMPEGNO



Item	Order	Description	Model	OEM
1	416881	400W/230 V	SCB2, FLXS, FLXC1A, FV53, SCB1	VETRRES01 VETRRESSCB80
2	416882	500W/230 V	FV63	VETRRES02

Fry tops



Item	Order	Description	Model	OEM
1	416880	1700 W/230 V	FRY-TOP 60	GRILLRES04
2	375002	thermostat		GRILLTERMOS
3	111584	knob		GRILLTERMOSMA




Item	Order	Description	Model	OEM
1	390323	safety thermostat	FRY-TOP 60	VETRTERMSICU
2	359143	signal lamp		GRILLLAMPAD


Cookers




Item	Order	Description	Model	OEM
1	490129	1500 W/230 V	EK1, EK2-2	SNACKPIAS1
2	490130	2000 W/230 V	EK2-1	SNACKPIAS2



Item	Order	Description	Model	OEM
1	300177	switch	EK1	SNACKCOMMUT
2	111550	knob	EK2-2	SNACKMANCUC
3	359143	signal lamp	EK2-1	GRILLLAMPAD



Item	Order	Description	Model	OEM
1	416884	700 W/230 V	FV75	VETRRES03
2	416885	900 W/230 V	FV100	VETRRES04
3	416886	750 W/230 V	FSP60, FSP100	SCALDRESIST



Item	Order	Description	Model	OEM
1	390006	thermostat	FV53, FV63, FV75, FV100, FSP60, FSP100, SCP1, SCB2, FLXC, FLXC/A	VETRETERMOS
2	111550	knob		VETREMANTERM
3	390323	safety thermostat		VETRETERMSICU




Item	Order	Description	Model	OEM
1	301003	switch	FV_1, FLXC, FLXC/A	TOSTINTER
2	359143	signal lamp		VETRGEEMMA
3	359374	signal lamp	SCB1, SCB2,	TOSTGEMMA
4	359143	signal lamp	FSP60, FSP100	GRILLLAMPAD


F

Suitable for Forved


Bains-marie/sausage warmers




Item	Order	Description	Model	OEM
1	416887	1200 W/230 V	BM	SNACKRESIS01
2	416880	1700 W/230 V	CW1, CW2	GRILLRES04
3	301003	switch	-	TOSTINTER



Item	Order	Description	Model	OEM
1	300176	main switch		03227/B
2	111549	knob		3131
3	359814	signal element	FR_, FLT_	3676
4	359815	insert lamp holder/clear		3066
5	359816	insert lamp holder/green		3067




Item	Order	Description	Model	OEM
1	375620	thermostat	CW1, CW2	VETRTER120
2	390006	thermostat	BM	VETRTERMOS
3	110100	knob	CW1, CW2, BW	VETRMANTERM
4	390323	safety thermostat		VETRTERMSICU



Item	Order	Description	Model	OEM
1	375543	thermostat	FR_, FLT_	3064
2	111550	knob		3096
3	375290	safety thermostat	FLT	03299/A


Fryers



Item	Order	Description	Model	OEM
1	416888	3500 W/7230 V	FR6, FR6+6, FR7, FR7+7, FLT8B, FLT8+8B	3955
2	416889	2000 V/230 V	FLT8S, FLT8+8S	3966
3	416890	1670 W/230 V	FLT12, FLT12+12	3111



Item	Order	Description	Model	OEM
1	375542	safety thermostat	FR	9004
2	345255	micro switch	FR_, FLT	03041/A
3	380238	protection		9023




Item	Order	Description	Model	OEM
1	416891	3000 W/7230 V	FLT12S, FLT12+12S, FLT30B, FLT30M, FLT20, FLT20+20	3108
2	416892	4000 W/230 V	FLT20BS, FLT20+20BS	3108A



Item	Order	Description	Model	OEM
1	540952	drain tap	FLT	3964
2	540863	drain pipe		3962



Item	Order	Description	Model	OEM
1	540747	drain tap	FR8	FRIGRUBINFR8
2	540910	drain tap	FLT_M	3118



Item	Order	Description	Model	OEM
1	970375	fryer basket	FLT20	FRIGCEST20
2	970376	fryer basket	FLT30	3323



Item	Order	Description	Model	OEM
1	970372	fryer basket	FLT8B	3960
2	970373	fryer basket	FRG, FR7, FLT8BS	3967
3	970374	fryer basket	FLT126	3961