


Spare parts suitable for: **POTIS**

Spare parts suitable for single devices




Gyros grills (gas)




Item	Order	Description	Model	OEM
1	104281	burner/complete	GD1, GD3, GD4,	PT0006
2	104280	burner/complete	GD5	PT0005
3	104282	ceramic plate	universal	PT0007

Burning grids



Item	Order	Dimensions/mm	Model	OEM
1	850025	350 x 160	G1 old	PT0270
2	850026	480 x 160	G2 old	PT0271
3	850027	590 x 160	G3 old	PT0272



Item	Order	Dimensions/mm	Model	OEM
1	850028	180 x 115	G1, G2, G3	PT0290
2	850031	170 x 165	GD1	PT0265
3	850032	205 x 160	GD2	PT0266
4	850029	230 x 150	GD3, GD4, GD5 GH	PT0291



Item	Order	Description	Model	OEM
1	101638	gas tap		PT0085 PT0086
2	110149	knob	G1, G2, G3, GD1, GD2,	PT0114
3	102119	thermocouple (new)	GD3, GD4	PT0243
4	102128	thermocouple		PT0241
5	102067	nut, M8 x 1		



Item	Order	Description	G-type	OEM
1	101299	nut, M12 x 1	G1, G2,	
2	101277	olive, 8mm	G3, GD1,	PT0010
3	101296	union nut, M12 x 1/8mm	GD2,	PT0244
4	101234	solenoid coil nut, M15 x 1/M8 x 1	GD3,	
5	101051	solenoid coil	GD4, GH	PT0150



Item	Order	Description	Model	OEM
1	415104	1000W/230 V	EH	PT0212
2	415562	1300W/230 V	E1, E2, E3	PT0094
2	415563	1500W/230 V		PT0095
3	850030	ceramic stone		PT0106



Item	Order	Description	Model	OEM
1	500070	motor, complete, 230 V, 1 U/min		PT0153
2	500502	motor, complete, 230 V, 2 U/min		PT0156
2	500503	motor, complete, 12 V, 1 U/min		PT0162



Item	Order	Description	Model	OEM
1	300025	7-position switch		PT0177
2	300004	7-position switch		PT0178
3	110234	knob		PT0113



Item	Order	Description	Model	OEM
4	359430	signal lamp		PT0118
5	359260	lamp holder yellow		
6	345575	switch, 1-0-2		PT0176



Item	Order	Description	Model	OEM
1	550054	lamp holder outlet with fuse	universal	PT0206
2	358603	fine fuse (10 pieces)		PT0195
3	550241	plug with switch		PT0207